PORSCHE

Minor Maintenance Checklist – Cayenne V6 (M.Y. 2008)

Required Maintenance and Lubrication Service

Minor Maintenance (Labor Operation 03 24 00 ..) See Technical Manual After 18,000, 54,000, 90,000, 126,000 miles etc. / 30,000, 90,000, 150,000, 210,000 km etc.

Note: If the mileage for scheduled maintenance is not reached, minor maintenance must be performed no later than after 2, 6, 10..... years.

The terms 'check' and 'inspection' include all necessary subsequent work such as adjusting, readjusting, correcting and topping off, but do not include repairing, replacing and reconditioning parts or assemblies.

Diagnosis system: Read out fault memory; reset maintenance interval
Underside of vehicle and engine compartment: Visual inspection for leaks (oil and fluids)
Engine compartment: Visual inspection for damage
Underbody covers: Visual inspection, check that all are securely fastened – replace any damaged or missing panels
Change engine oil and oil filter (Cayenne V6 which is 10,000 miles/15,000 km, see separate Oil Change Sheet, PNA 000 162 CC)
PDCC: Check fluid level
Check drive belt
Coolant hoses: Check condition
Radiators and air intakes: Visual inspection for exterior debris and blockage
Coolant: Check level and antifreeze protection level
Brake system: Visual inspection of the brake pads and brake discs for signs of wear
Brake hoses and lines: Visual inspection for damage, correct routing and corrosion Check brake fluid level
Check tightness of bolts on the suspension adjustment system at the front and rear (only applies to the first service)
Axle shafts: Visual inspection of the dust boots for leaks & signs of damage
Drive shafts: Visual inspection of the sleeves for leaks & signs of damage)
Tires, external spare wheel: Check condition and tire pressure
Check firewall body drains for debris
Panorama roof: Adapt control module
Windshield wiper/washer system, headlight washer: Check function, fluid level, nozzle adjustment, and antifreeze prot
tion level, check wiper blades
Uvehicle lighting: Check operation
All headlights: Check adjustment
Horn: Check operation
Batteries and ventilation hoses: Check condition
Electrical equipment as well as indicator and warning lights: Check operation
Additional Maintenance every 36,000 miles / 60,000 km or 4 years (Labor Operation 03 81 00)
Replace spark plugs

Replace spark plugs

Additional Maintenance every 54,000 miles / 90,000 km or 6 years (Labor Operation 03 83 00 ..)

Replace PDCC reservoir

Additional Maintenance every 72,000 miles / 120,000 km or 4 years (Labor Operation 03 85 00 ..)

Air filter element/s should be changed more often dependent on vehicle use and operation in dusty environments.

Air filter element/s (1 or 2 dependent on options)

Additional Maintenance every 144,000 miles / 240,000 km or 16 years

- Change front differential oil
- Change rear differential drive oil
- Change transfer case oil
- Change manual transmission oil
- Change Tiptronic transmission oil and ATF filter

Additional Maintenance every 2 years

Change brake fluid (use only Original Porsche Brake Fluid)

Additional Maintenance every 4 years

Replace tire sealant

Additional Maintenance every 4 years – then every 2 years

Check battery for tire pressure monitoring system

Additional Maintenance after 10 years – then every 2 years

Airbag system: Check operation and condition

Road Test Check

 Remote control, front seats, foot brake and parking brake (also operating travel), engine, clutch, steering, transmission, ParkAssist, automatic speed control, PSM switches, heater, air-conditioning system and instruments: Check operation Oils, fluids: Visual inspection for leaks Road Test Performed - Technician Signature: 		
VIN: WP1		
Mileage (check one) 🔲 Miles 🛄 Kilometers:		
Dealer Name:	Dealer Code:	
Repair Order #:		
Technician Name:		
Technician Signature:		