

Intermediate Maintenance Checklist – 911 GT3/GT3 RS (991) (2015-16)

Required Maintenance and Lubrication Service

et. . .

* **Oil Change** Every 12,000 miles (20,000 km) or 1 year. Built up to week 44/2014 **See Below Check Box**. **Oil Change** Every 6,000 miles (10,000 km) or 1 year. Built from week 45/2014 **See Below Check Box**.

□ Intermediate Maintenance (Labor Operation 03 14 00 ..) See Technical Manual

After 12,000, 36,000, 60,000, 84,000 miles (20,000, 60,000, 100,000, 140,000 km) etc.

Note: If the mileage for scheduled maintenance is not reached, intermediate maintenance must be performed no later than after 2, 6, 10..... years.

The terms 'check' and 'inspection' include all necessary subsequent work such as adjusting, readjusting, correcting and topping off, but do not include repairing, replacing and reconditioning parts or assemblies.

LIECTRICS		
Diagnosis system: Read out fault memory; reset maintenance interval		
Uindshield wiper/washer system, headlight washer: Check function and nozzle adjustment		
Horn: Check operation		
Tires: Check tire pressure (TPM)		
Electrical equipment as well as indicator and warning lights: Check operation		
Inside of Vehicle		
Pollen filter: Replace filter element		
Front Luggage Compartment		
Pollen filter: Replace pre-filter element		
Check front lid lock and safety hook of the front lid for secure seating and function properly		
Uindshield wiper/washer system, headlight washer: Check fluid level and antifreeze protection level		
Check firewall body drains for debris		
Outside of Vehicle		
Check wiper blades		
Uvehicle lighting: Check operation		
All headlights: Check adjustment		
Radiators and air intakes: Visual inspection for exterior debris and blockage		
Check central lock on wheels		
Under the Vehicle		
Drain engine oil		
Tires: Check condition		
Brake system: Visual inspection of the brake pads & brake discs for wear (w/o removing wheels) (Except PCCB)		
Uvehicles with PCCB: Brake discs must be checked for wear during every service and whenever brakes pads are		
replaced using special tool VAS 6813. Please refer to workshop manual for work procedure.		
Brake hoses and lines: Visual inspection for damage, correct routing and corrosion Check brake fluid level		
Axle shafts: Visual inspection of the dust boots for leaks & signs of damage		
Rear axle steering: Check bellows, dust boots and joints for play		
Check that threaded connections for front & rear chassis adjustment are secure		
Check vehicle height		
Control boxes for exhaust flaps: Check function		
Engine Compartment		
Change oil filter and fill engine oil (Every 12,000 miles/20,000 km, see separate Oil Change Sheet, PNA 000 162 FJ) Up to week 44/2014		
Change oil filter and fill engine oil (Every 6,000 miles/10,000 km, see separate Oil Change Sheet, PNA 000 162 FM) From week 45/2014		
Coolant: Check level and antifreeze protection level		
Check firewall body drains for debris		

Additional Maintenance - Replace Spark Plugs (Labor Operation 03 81 00 ...)

Replace spark plugs: every 12,000 miles / 20,000 km or 2 years

Additional Maintenance every 48,000 miles / 80,000 km or 6 years (Labor Operation 03 82 00 ...)

Additional Maintenance every 80,000 miles / 120,000 km or 4 years (Labor Operation 03 85 00 ..)

Additional Maintenance every 96,000 miles / 160,000 km or 12 years (Labor Operation 03 86 00 ..)

PDK transmission: change oil

Additional Maintenance every 2 years (Labor Operation 03 51 00 ..)

Change brake fluid (use only Original Porsche Brake Fluid)

Tire sealant (check expiration date and replace as necessary)

Inspection Performed - Technician Signature: _

Road Test Check

Remote control, front seats, foot brake and electric parking brake (also operating travel), engine, clutch, steering,		
transmission, cruise control, ESC Off switch, ESC + TC Off switch, PASM switch, Racetrack switch, Lift switch, sports		
exhaust system, air-conditioning system and instruments: Check operation		
Oile fluides Visual increasing for larks		

Oils, fluids: Visual inspection for leaks

Road Test Performed - Technician Signature:		
Customer Name:	Date://	
VIN: WPO	_	
Mileage (check one) 🛄 Miles 🛄 Kilometers:		
Dealer Name:	Dealer Code:	
Repair Order #:		
Technician Name:		
Technician Signature:		