

Maintenance (C markets*) 911 R (991) as of 2016 model

Vehicle Ident. No.	for order no.
☐ Maintenance at 40000, 80000, 120000, 160000 km / 24000, (Labour operation: 03 16 00) For descriptions of the individual maintenance tasks Note:If the mileage for a regular service is not reached	
The term "checking" includes all necessary subsequent opping up, but does not include repairing, replacing ar	
Electrics	
Windscreen wiper/washer system, headlight cleaning s	system: check function
Horn: check function	
Tyres: check tyre pressure (TPM)	
Diagnostic system: read out fault memory; reset mainte	enance interval
Inside the vehicle	
Particle filter: replace filter element	
Seat belts: check function and condition	
Door locks: check function	
Luggage compartment	
Check front lid lock and safety hook of the front lid to e	nsure that they are secure and function properly
Replace air intake pre-filter	
	eck window cleaner and antifreeze, depending on time of
year, only use windscreen cleaners approved by Porso	:he
Outside the vehicle	
Mix fuel in fuel tank with additive [Keropur from Porsch	e, Part No. 00004320902 (China only)]
Check wiper blades	
All headlights: check adjustment	
Radiators and air intakes: visual inspection for externa	
Brake system: check brake pads and brake discs for w	rear
Brake hoses: visual inspection for damage	
Check central lock on wheels	
Under the vehicle	
Drain engine oil	
Change oil filter	
Underbody panels: visual inspection for completeness	, secure installation and damage
Tyres: check condition	
Visual inspection for leaks from underneath (oils and o	
Brake lines: visual inspection for damage, routing and	
Steering gear: visual inspection of the bellows for dama	age
Tie rod joints: check play and dust bellows	
Drive shafts: visual inspection of the boots for leaks an	
Axle joints: check the play and visually inspect the dus	
Rear-axle steering: check bellows, dust boots and play	
Check that threaded connections for chassis adjustme	nt at front and rear are secure
Check vehicle height	ve shook angina maunt
Exhaust system: visual inspection for leaks and damage	ge, check engine mount
Control boxes for exhaust flaps: check function	



Maintenance (C markets*) 911 R (991) as of 2016 model

Vehicle Ident. No.	Work instruction for order no.	
Engine compartment		
Air cleaner: replace filter elements		
Replace drive belt		
Fill in engine oil		
Throttle housing: clean inside (China only)		
Fuel lines and connections: visual inspection		
Coolant: check level and antifreeze		

^{*} For country allocation, see overview of A, B and C markets



Maintenance (C markets*) 911 R (991) as of 2016 model

Vehicle Ident. No.	Work instruction for order no.	
☐ Additional maintenance every 2 years (Labour operation: 03 51 00)		
Change brake fluid (use only original Porsche brake f	fluid)	
Prepare condition report for long-life guarantee		
Tyre sealing compound: check use-by date and replace if necessary		
☐ Additional maintenance for spark plugs		
every 20000 km / 12000 miles or every year	ır	
(Labour operation: 03 81 00)		
Replace spark plugs		
☐ Additional maintenance every 120000 km /	/ 72000 mls or every 4 years	
(Labour operation: 03 85 00)		
Ancillary unit mounts and chassis: visual inspection of		
☐ Additional maintenance every 160000km / (Labour operation: 03 86 00)	96000mls or every 12 years	
Manual transmission: change oil		
Signature (mechanic): Test drive:		
Remote control, front seats, electric parking brake and transmission, cruise control, ESC Off switch, ESC + 1 exhaust system, heating, air conditioning and instrum	TC Off switch, PASM switch, Sport switch, Lift switch, sports	
Oils, fluids: visual inspection for leaks		
Signature (final check):		
	Porsche Centre	