



PORSCHE

Inspection Sheet
911 GT3/GT3 RS/GT2 RS
 as of 2018 model

Name		Date	
License No.		Mileage/km	
VIN		Repair Order	

Inspection At 12,000, 24,000, 36,000, 48,000 miles/20,000, 40,000, 60,000, 80,000 km etc.
 (For descriptions of the individual maintenance tasks, see PIWIS Information System Workshop Manual).

Note If the mileage for an inspection is not reached, an inspection must be carried out every 2 years at the latest.
 The term 'checking' includes all necessary subsequent work, such as adjustments, readjustments, corrections and topping up, but does not include repairs, replacements or overhaul of parts or assemblies.

Measures		911 GT3	GT3 RS	GT2 RS	Every 12 tmls/20 tkm or 2 years	Every 24 tmls/40 tkm or 4 years	Every 48 tmls/80 tkm or 6 years	Every 72 tmls/120 tkm or 4 years	Every 96 tmls/160 tkm or 12 years	Time-dependent
	Electrics	Windshield wiper/washer system, headlight cleaning system: check function	●	●	●	<input type="checkbox"/>				
		Horn: check function	●	●	●	<input type="checkbox"/>				
		Tires: check tire pressure (TPM)	●	●	●	<input type="checkbox"/>				
		Diagnostic system: read out fault memory; reset maintenance interval	●	●	●	<input type="checkbox"/>				
		Check parking brake actuator travel	●	●	●	<input type="checkbox"/>				
		Water spray system: perform drive link test			●	<input type="checkbox"/>				
	Inside the vehicle	Pollen filter: replace filter element	●	●	●	<input type="checkbox"/>				
		Seat belts: check function and condition	●	●	●	<input type="checkbox"/>	<input type="checkbox"/>			
		Door locks: check function	●	●	●	<input type="checkbox"/>	<input type="checkbox"/>			
	Luggage compartment	Check front lid lock and safety hook of the front lid to ensure that they are secure and function properly	●	●	●	<input type="checkbox"/>				
		Replace air intake pre-filter	●	●	●	<input type="checkbox"/>				
		Windschield wiper/washer system: check fluid level; check window cleaner and antifreeze, depending on time of year, only use windshield cleaners approved by Porsche	●	●	●	<input type="checkbox"/>				
		Check front firewall body drains for debris			●	<input type="checkbox"/>				
		Water spray system: change filter			●	<input type="checkbox"/>				
		Water spray system: check fluid level			●	<input type="checkbox"/>				

■ Carry out depending on mileage/age (Please check)
 ● Relevant model line



PORSCHE

Inspection
911 GT3/GT3 RS/GT2 RS
 as of 2018 model

		Measures			911 GT3	GT3 RS	GT2 RS	Every 12 tmls / 20 tkm or 2 years	Every 24 tmls / 40 tkm or 4 years	Every 48 tmls / 80 tkm or 6 years	Every 72 tmls / 120 tkm or 4 years	Every 96 tmls / 160 tkm or 12 years	Time-dependent
	Outside the vehicle	Check wiper blades	•	•	•	<input type="checkbox"/>							
		All headlights: check adjustment	•	•	•	<input type="checkbox"/>							
		Radiators and air intakes: visual inspection for external contamination and blockage	•	•	•	<input type="checkbox"/>							
		Brake system*: check brake pads and brake discs for wear	•	•	•	<input type="checkbox"/>	<input type="checkbox"/>						
		Brake system: check brake pads and brake discs for wear (without removing wheels)	•	•	•	<input type="checkbox"/>	<input type="checkbox"/>						
		Check central lock on wheels	•	•	•	<input type="checkbox"/>	<input type="checkbox"/>						
	Under the vehicle	Drain engine oil (See separate Oil Maintenance Sheet PNA 000 162 FP)	•	•	•	<input type="checkbox"/>							
		Change oil filter	•	•	•	<input type="checkbox"/>							
		Underbody panels: visual inspection for completeness, secure installation and damage	•	•	•	<input type="checkbox"/>	<input type="checkbox"/>						
		Tires: check condition	•	•	•	<input type="checkbox"/>	<input type="checkbox"/>						
		Visual inspection for leaks from underneath (oils and other fluids)	•	•	•	<input type="checkbox"/>	<input type="checkbox"/>						
		Brake lines: visual inspection for damage, routing and corrosion	•	•	•	<input type="checkbox"/>	<input type="checkbox"/>						
		Brake hoses: visual inspection for damage	•	•	•	<input type="checkbox"/>	<input type="checkbox"/>						
		Steering gear: visual inspection of the bellows for damage	•	•	•	<input type="checkbox"/>	<input type="checkbox"/>						
		Tie rod joints: check play and dust bellows	•	•	•	<input type="checkbox"/>	<input type="checkbox"/>						
		Drive shafts: visual inspection of the boots for leaks and damage	•	•	•	<input type="checkbox"/>	<input type="checkbox"/>						
		Axle joints: check the play and visually inspect the dust boots for damage	•	•	•	<input type="checkbox"/>	<input type="checkbox"/>						
		Rear-axle steering: check bellows, dust boots and play on joints	•	•	•	<input type="checkbox"/>	<input type="checkbox"/>						
		Anti-roll bar and connecting links: visual inspection for damage	•	•	•	<input type="checkbox"/>	<input type="checkbox"/>						
		Check that threaded connections for chassis adjustment at front and rear are secure	•	•	•	<input type="checkbox"/>	<input type="checkbox"/>						
		Check vehicle height	•	•	•	<input type="checkbox"/>	<input type="checkbox"/>						
Control boxes for exhaust flaps: check function	•	•	•	<input type="checkbox"/>	<input type="checkbox"/>								

* Vehicles with PCCB: PCCB Brake discs must be checked for wear during every service and whenever brakes pads are replaced using special tool VAS 6813.

Carry out depending on mileage/age (Please check)
 Relevant model line



PORSCHE

Inspection
911 GT3/GT3 RS/GT2 RS
 as of 2018 model

		911 GT3	GT3 RS	GT2 RS	Every 12 tmls / 20 tkm or 2 years	Every 24 tmls / 40 tkm or 4 years	Every 48 tmls / 80 tkm or 6 years	Every 72 tmls / 120 tkm or 4 years	Every 96 tmls / 160 tkm or 12 years	Time-dependent	
	Measures Under the vehicle	Exhaust system: visual inspection for leaks and damage, check engine mount	●	●	●	<input type="checkbox"/>					
		Replace spark plugs	●	●	●	<input type="checkbox"/>					
		PDK transmission: change clutch fluid	●	●	●		<input type="checkbox"/>				
		PDK transmission: change transmission oil	●	●	●				<input type="checkbox"/>		
		Manual transmission: change oil	●							<input type="checkbox"/>	
		Ancillary unit mounts and chassis: visual inspection of all rubber mountings and boots for damage	●	●	●			<input type="checkbox"/>			
	Engine compartment	Fill in engine oil (See separate Oil Maintenance Sheet PNA 000 162 FP)	●	●	●	<input type="checkbox"/>					
		Coolant: check level and antifreeze	●	●	●	<input type="checkbox"/>					
		Replace drive belt	●	●	●		<input type="checkbox"/>				
		Fuel lines and connections: visual inspection	●	●	●		<input type="checkbox"/>				
		Air cleaner: replace filter elements	●	●	●		<input type="checkbox"/>				
		Check rear firewall body drains for debris	●	●	●	<input type="checkbox"/>					
	Additional work every 2 years	Change brake fluid (use only original Porsche brake fluid)	●	●	●					<input type="checkbox"/>	
		Tire sealing compound: check use-by date and replace if necessary	●	●	●						<input type="checkbox"/>
	Test drive	Remote control, front seats, electric parking brake and foot brake (also actuation travel), engine, steering, transmission, cruise control, ESC Off switch, ESC + TC Off switch, PASM switch, Sport switch, Lift switch, sports exhaust system, heating, air conditioning and instruments: check function	●	●	●	<input type="checkbox"/>					
		Oils, fluids: visual inspection for leaks	●	●	●	<input type="checkbox"/>					

Signature (technician): _____



Porsche Dealer Stamp

Carry out depending on mileage/age (Please tick)
 Relevant model line