

Inspection Macan

as of 2019 model

Name			Date								
License No.			Mileage/km								
VIN			Repair Order								
Inspection		At 20,000, 40,000, 60,000, 80,000 miles/30,000, 6 (For descriptions of the individual maintenance tasks,			пор М	anual).					
Note		If the mileage for an inspection is not reached, an insp years at the latest. The term 'checking' includes all necessary subsequen readjustments, corrections and topping up, but does overhaul of parts or assemblies.	nt work, such as adjustment	s,	le	Every 20 tmls/30 tkm or 2 years	Every 30 tmls/45 tkm or 4 years	Every 40 tmls/60 tkm or 4 years	Every 80 tmls/120 tkm or 4 years	Every 160 tmls/240 tkm or 16 years	Time-dependent
		Measures			Macan	Ever	Ever	Ever	Ever	Ever	Time
		Windshield wiper/washer system, headlight cleaning system, settings	ystem: check function and r	nozzle	•						
	rics	Horn: check function			•						
	Electrics	Tires: check tire pressure (TPM)			•						
		Diagnostic system: read out fault memory and transfer maintenance interval		•							
	Inside the vehicle	Pollen filter: replace filter element			•						
	Insid veh	Seat belts: check function and condition			•						
		Check wiper blades			•						
		All headlights: check adjustment									
		Tires and spare wheel: check condition			•						
	Ð	Brake system: check brake pads and brake discs for wear (without removing wheels)									
	utside th vehicle	Brake system: check brake pads and brake discs for we	ar		•						
<u> </u>	Outside the vehicle	Vehicles with PCCB: PCCB Brake discs must be checke service and whenever brakes pads are replaced using s VAS 6813			•						
		Trailer hitch: check function			•						
		Lubricate door arrester and fastening bolts			•						

Relevant model line



Inspection Macan as of 2019 model

			Measures	Macan	Every 20 tmls/30 tkm or 2 years	Every 30 tmls/45 tkm or 4 years	Every 40 tmls/60 tkm or 4 years	Every 80 tmls/120 tkm or 4 years	Every 160 tmls/240 tkm or 16 years	Time-dependent
	Outside the	utside the vehicle	Radiators and air intakes: visual inspection for external contamination and blockage	•						
	0 Ite	θ Λ	Check front firewall body drains for debris	•						
			Underbody panels: visual inspection for completeness, secure installation and damage	•						
			Drain engine oil (See separate Oil Maintenance Sheet PNA 000 162 NE)	•						
			Visual inspection for leaks from underneath (oils and other fluids)	•						
			Brake lines: visual inspection for damage, routing and corrosion	•						
			Brake hoses: visual inspection for damage	•						
			Drive shafts: visual inspection of the boots for leaks and damage	•						
	Inder the	vehicle	Cardan shaft: visual inspection of the rubber bellows for damage	•						
<u>×</u>	abul	veh	Steering gear: visual inspection of the bellows for damage	•						
			Tie rod joints: check play and dust bellows	•						
			Axle joints: check the play and visually inspect the dust boots for damage	•						
			Exhaust system: visual inspection for leaks and damage, check engine mount	•						
			PDK transmission: change oil and filter	•						
			All-wheel final drive: change oil	•						
			Rear final drive: change oil	•						
Enoire Troise		Change oil filter (See separate Oil Maintenance Sheet PNA 000 162 NE)	•							
			Fill in engine oil	•						
		IJ	Windshield wiper/washer system: check fluid level; check window cleaner and antifreeze, depending on time of year, only use windshield cleaners approved by Porsche	•						
	٩ با	Engine compartment	Coolant: check level and antifreeze	•						
			Check drive belt (only if vehicle is used for off-road driving)	•						
		5	Visual inspection for leaks from above (oils and other fluids)	•						
			Fuel lines and connections: visual inspection	•						
			Replace spark plugs	•						

• Relevant model line



Inspection Macan as of 2019 model

		Measures	Macan	Every 20 tmls/30 tkm or 2 years	Every 30 tmls/45 tkm or 4 years	Every 40 tmls/60 tkm or 4 years	Every 80 tmls/120 tkm or 4 years	Every 160 tmls/240 tkm or 16 years	Time-dependent
	Engine compartment	Air cleaner: replace filter element	•						
+	Additional work every 2 years	Change brake fluid (use only original Porsche brake fluid) Tire sealing compound: check use-by date and replace if necessary	•						
X	Test drive	Remote control, front seats, electric parking brake and footbrake, engine, transmission, steering, ParkAssist, cruise control, PSM switch, heating, sports exhaust system, air conditioning and instruments: check function Oils, fluids: visual inspection for leaks	•						

Signature (technician):

Porsche Dealer Stamp

Relevant model line