

**Major Maintenance Checklist – Carrera GT (USA & Canadian Vehicles Only)**

Required Maintenance and Lubrication Service

- Major Maintenance** (Labor Operation 03 26 00 ..) See Technical Manual  
After 30,000, 60,000, 90,000, 120,000 miles (48,000, 96,000, 144,000, 192,000 km) etc.

- Diagnosis system: Read fault memory
- Change engine oil and oil filter
- Change manual transmission oil and oil filter
- Replace drive belt
- Check valve clearance
- Replace spark plugs
- Power steering: Check fluid level
- Vehicle underside and engine compartment: Visual inspection for leaks (oils and fluids) and abrasion (lines and hoses);  
Underbody panels: visual inspection for completeness, installation and damage
- Coolant hoses: Check condition  
Radiators and air intakes: Visual inspection for external debris and blockage  
Coolant: Check level and antifreeze
- Air filter: Replace filter element
- Air filter housing: Visual inspection for contamination
- Pollen filter: Replace filter element
- Fuel lines and connections: Visual inspection for damage and leaks
- Wheel securing device: Check function  
Wheel nuts: Visual inspection for wear
- Brake system: Visual inspection of the brake pads and brake discs for wear
- Parking brake: Check free play of parking brake lever
- Brake hoses and lines: Visual inspection for damage, routing and corrosion  
Check brake fluid level
- Clutch: Check the pedal play and end position
- Throttle actuation: Check for smooth operation, check full throttle position with the PST2 tester
- Steering gear: Visual inspection of the dust boots for damage  
Tie rod ends: Check play and dust boots
- Axle joints: Check play; visual inspection of the dust boots for damage, check that the front axle ball joints and the screw connections of the front and rear running gear adjustment points are secure
- Drive shafts: Visual inspection of the dust boots for leaks and damage
- Exhaust system: Visual inspection for leaks and damage; check mounting and heat shields
- Magnesium wheels: Visual inspection for corrosion or damage
- Tires: Check condition and tire pressure
- Check the door, lid locks and safety hook of the front lid for secure seating and function
- Removable roof panels: Check operation
- Spoiler drive: Check fluid level, function and end position
- Vehicle lighting: Check function  
All headlights: Check setting
- Horn: Check function
- Windshield wiper/washer system, headlight washer: Check fluid level and nozzle settings (use winter antifreeze protection during winter months)
- Seat belts: Check function and condition
- Electrical equipment, warning and indicator lights: Check function

**Additional maintenance every 60,000 miles (96,000 km) Labor operation 03 84 00 ..**

- Replace additional spring on front spring strut

**Every 2 years**

- Change brake fluid
- Pedals: Visual inspection for contamination and leaks

**Every 4 years**

- Replace tire sealant

**After 4, 8, 10, then every 2 years**

- Inspect airbag system
- Unit mount: Visual inspection of all hydraulic mounts for damage

Inspection Performed - Technician Signature: \_\_\_\_\_

**Road Test Check**

- 
- Remote control, seats, foot and parking brake (also actuation travel), engine, clutch, steering, transmission, rear spoiler, heating, air-conditioning system and instruments: Check function
- 
- Oils, fluids: Visual inspection for leaks
- 

Road Test Performed - Technician Signature: \_\_\_\_\_

**Scheduled Maintenance Points**

The terms "inspect" and "check" include all associated work such as checking the condition, adjustments, readjustments, corrections and replenishment. They do not include the repair, replacement or overhaul of components or assemblies. The maintenance points are valid for all vehicle types of the model line in question.

The recommended service intervals and scope of work apply under normal driving conditions and do not take into account all optional equipment. Dusty areas require more frequent checking and possible replacement of the air filter elements. The radiators and cooling air inlets in the front should be checked and cleaned regularly if the car is driven on very dirty roads. Tire, clutch and brake wear as well as the condition of the engine oil are all largely dependent on driving habits, and operating conditions. You should perform maintenance on these items more frequently under such operating conditions. Proper care and maintenance will preserve the value of your Porsche and safeguard its functional capability.

**Note:** On vehicles with annual mileages of less than 10,000 miles (15,000 km), an annual maintenance must be performed once a year. For an annual mileage of more than 10,000 miles (15,000 km) it is recommended to perform the next scheduled minor or major maintenance. If the mileage for scheduled maintenance is not reached, minor maintenance must be performed no later than after 2, 6, 10..... years.

---

**Customer Name:** \_\_\_\_\_ **Date:** \_\_\_\_/\_\_\_\_/\_\_\_\_

**VIN: WPO** \_\_\_\_\_

**Mileage** (check one)  Miles  Kilometers: \_\_\_\_\_

**Dealer Name:** \_\_\_\_\_ **Dealer Code:** \_\_\_\_\_

**Repair Order #:** \_\_\_\_\_

**Technician Name:** \_\_\_\_\_

**Technician Signature:** \_\_\_\_\_