

Minor Maintenance Checklist – Carrera GT (USA & Canadian Vehicles Only)

Required Maintenance and Lubrication Service

- Minor Maintenance** (Labor Operation 03 24 00 ..) See Technical Manual
After 15,000, 45,000, 75,000, 105,000 miles (24,000, 72,000, 120,000, 168,000 km) etc.

Note: On vehicles with annual mileages of less than 10,000 miles (15,000 km), an annual maintenance must be performed once a year. For an annual mileage of more than 10,000 miles (15,000 km) it is recommended to perform the next scheduled minor or major maintenance. If the mileage for scheduled maintenance is not reached, minor maintenance must be performed no later than after 2, 6, 10..... years.

The terms 'check' and 'inspection' include all necessary subsequent work such as adjusting, readjusting, correcting and topping off, but do not include repairing, replacing and reconditioning parts or assemblies.

-
- Diagnosis system: Read fault memory
-
- Change engine oil and oil filter
-
- Replace drive belt
-
- Power steering: Check fluid level
-
- Vehicle underside and engine compartment: Visual inspection for leaks (oils and fluids) and abrasion (lines and hoses); Underbody panels: visual inspection for completeness, installation and damage
-
- Coolant hoses: Check condition
Radiators and air intakes: Visual inspection for external debris and blockage
Coolant: Check level and antifreeze
-
- Air filter: Replace filter element
-
- Air filter housing: Visual inspection for contamination
-
- Pollen filter: Replace filter element
-
- Fuel lines and connections: Visual inspection for damage and leaks
-
- Wheel securing device: Check function
Wheel nuts: Visual inspection for wear
-
- Brake system: Visual inspection of the brake pads and brake discs for wear
-
- Brake hoses and lines: Visual inspection for damage, routing and corrosion
Check brake fluid level
-
- Drive shafts: Visual inspection of the dust boots for leaks and damage
-
- Exhaust system: Visual inspection for leaks and damage; check mounting and heat shields
-
- Magnesium wheels: Visual inspection for corrosion or damage
-
- Tires: Check condition and tire pressure
-
- Check the door, lid locks and safety hook of the front lid for secure seating and function
-
- Removable roof panels: Check operation
-
- Spoiler drive: Check fluid level, function and end position
-
- Vehicle lighting: Check function
All headlights: Check setting
-
- Horn: Check function
-
- Windshield wiper/washer system, headlight washer: Check fluid level and nozzle settings (use winter antifreeze protection during winter months)
-
- Seat belts: Check function and condition
-
- Electrical equipment, warning and indicator lights: Check function
-

Additional maintenance every 60,000 miles (96,000 km) Labor operation 03 84 00 ..

- Replace additional spring on front spring strut
-

Every 2 years

- Change brake fluid
-
- Pedals: Visual inspection for contamination and leaks
-

Every 4 years

- Replace tire sealant
-

After 4, 8, 10, then every 2 years

- Inspect airbag system
-
- Unit mount: Visual inspection of all hydraulic mounts for damage
-

Inspection Performed - Technician Signature: _____

Road Test Check

- Remote control, seats, foot and parking brake (also actuation travel), engine, clutch, steering, transmission, rear spoiler, heating, air-conditioning system and instruments: Check function
- Oils, fluids: Visual inspection for leaks

Road Test Performed - Technician Signature: _____

Customer Name: _____ **Date:** ____/____/____

VIN: WPO _____

Mileage (check one) **Miles** **Kilometers:** _____

Dealer Name: _____ **Dealer Code:** _____

Repair Order #: _____

Technician Name: _____

Technician Signature: _____