

Intermediate Maintenance Checklist - 911 Turbo (997) (2009)

Required Maintenance and Lubrication Service (USA & Canadian Vehicles Only, Not For 911 GT2 (997), use separate checklist)

* Oil Change Every 10,000 miles (15,000 km) or 1 year. See Below Check Box.
Intermediate Maintenance (Labor Operation 03 14 00) See Technical Manual After 20,000, 60,000, 100,000, 140,000 miles (30,000, 90,000, 150,000, 210,000 km) etc. Note: If the mileage for scheduled maintenance is not reached, intermediate maintenance must be performed no later than after 2, 6, 10 years.
The terms 'check' and 'inspection' include all necessary subsequent work such as adjusting, readjusting, correcting and topping off, but do not include repairing, replacing and reconditioning parts or assemblies.
☐ Diagnosis system: Read fault memory; reset maintenance interval/Read and record range information on R.O. ☐ Change engine oil and oil filter (Every 10,000 miles/15,000 km, see separate Oil Change Sheet, PNA 000 162 EF) ☐ Vehicle underside and engine compartment: Visual inspection for leaks (oils and fluids) and abrasion (lines and hoses); ☐ Underbody panels: visual inspection for completeness, installation and damage
 □ Coolant hoses: Check condition Radiators and air intakes: Visual inspection for external debris and blockage Coolant: Check level and antifreeze protection level □ Pollen filter: Replace filter element
☐ Brake system: Visual inspection of the brake pads and brake discs for wear ☐ Brake hoses and lines: Visual inspection for damage, routing and corrosion ☐ Drive shafts: Visual inspection of the dust boots for leaks and damage
☐ Tires: Check condition and tire pressure ☐ Check firewall and cabrio section body drains for debris
 ☐ Check the door, lid locks and safety hook of the front lid for secure seating and function properly ☐ Vehicle lighting: Check function All headlights: Check setting ☐ Horn: Check function
 ☐ Horn: Check function ☐ Windshield wiper/washer system, headlight washer: Check fluid level and nozzle settings (use winter antifreeze protection during winter months) ☐ Check wiper blades
■ Battery: Check condition and electrolyte level ■ Electrical equipment, warning and indicator lights: Check function
Additional maintenance for spark plugs Labor operation 03 81 00 Replace spark plugs every 30,000 miles (45,000 km) or every 4 years
Additional maintenance for drive belt Labor operation 03 60 00
☐ Check drive belt at 40,000 miles (60,000 km) or every 4 years ☐ Check drive belt at 100,000 miles (150,000 km) or every 10 years ☐ Check drive belt at 160,000 miles (240,000 km) or every 16 years
Additional maintenance for convertible top Labor operation 03 70 00
☐ Maintain and care for convertible top at 20,000 miles (30,000 km) or every 2 years
Additional maintenance 60,000 miles (90,000 km) or every 6 years Labor operation 03 83 00 Replace drive belt Change all-wheel drive controller oil Replace fuel filter
Additional maintenance every 120,000 miles (180,000 km) or 12 years Labor operation 03 88 00
 □ Change manual transmission oil □ Change Tiptronic transmission oil and ATF filter □ Change Tiptronic transmission final drive oil □ Change front differential oil
Every 2 years
☐ Change brake fluid ☐ Check roll-over protection system (911 Cabriolet only)
Every 4 years
Replace tire sealant
After 4, then every 2 years
Check battery for the tire pressure monitoring system

After 4, 8, 10, then every 2 years Inspect airbag system Assembly and running gear mounts: Visual inspection of all rubber/hydraulic mounts for damage Inspection Performed - Technician Signature: Road Test Check				
			Remote control, front seats, foot brake and parking brake (also operating travel), engine, clutch, steering, transmission, ParkAssist, automatic speed control, PSM switch, PASM switch, Sport switch, heater, air-conditioning system and instruments: Check operation Oils, fluids: Visual inspection for leaks	
			Customer Name:	Date:/
VIN: WPO				
Mileage (check one) Miles Kilometers:				
Dealer Name:	Dealer Code:			
Repair Order #:				
Technician Name:				
Technician Signature:				