

**Intermediate Maintenance Checklist – Panamera S/Turbo (970) (2010)**

Required Maintenance and Lubrication Service (USA & Canadian Vehicles Only)

\* **Oil Change** Every 10,000 miles (15,000 km) or 1 year. **See Below Check Box.**

**Intermediate Maintenance** (Labor Operation 03 14 00 ..) See Technical Manual

After 20,000, 60,000, 100,000, 140,000 miles (30,000, 90,000, 150,000, 210,000 km) etc.

**Note:** If the mileage for scheduled maintenance is not reached, intermediate maintenance must be performed no later than after 2, 6, 10..... years.

The terms 'check' and 'inspection' include all necessary subsequent work such as adjusting, readjusting, correcting and topping off, but do not include repairing, replacing and reconditioning parts or assemblies.

Diagnosis system: Read fault memory; reset maintenance interval/Read and record range information on R.O.

Change engine oil and oil filter (Every 10,000 miles/15,000 km, see separate Oil Change Sheet, PNA 000 162 KC)

PDCC: Check fluid level

Radiators and air intakes: Visual inspection for external debris and blockage

Coolant: Check level and antifreeze protection level

Brake system: Visual inspection of the brake pads and brake discs for wear (without removing wheels)

Brake hoses and lines: Visual inspection for damage, routing and corrosion

Drive shafts: Visual inspection of the dust boots for leaks and damage

Tires: Check condition and tire pressure

Vehicle lighting: Check function

All headlights: Check setting

Horn: Check function

Windshield wiper/washer system, headlight washer: Check fluid level and nozzle settings (use winter antifreeze protection during winter months)

Check wiper blades

Clean reversing camera lense

Battery vent hoses: Check condition

**Additional maintenance for spark plugs** (Labor operation 03 81 00 ..)

Replace spark plugs: Panamera S every 40,000 miles (60,000 km) or every 4 years

Replace spark plugs: Panamera Turbo every 30,000 miles (45,000 km) or every 4 years

**Additional maintenance 60,000 miles (90,000 km) or every 6 years** (Labor operation 03 83 00 ..)

Replace PDCC reservoir

PDK transmission: Change oil

**Additional maintenance 80,000 miles (120,000 km) or every 4 years** (Labor operation 03 85 00 ..)

Air filter: Replace element

**Additional maintenance every 120,000 miles (180,000 km) or 12 years** (Labor operation 03 88 00 ..)

Change manual transmission oil

Change all-wheel front differential drive oil

Change rear differential oil

**Every 2 years** (Labor operation 03 51 00 ..)

Change brake fluid (use only genuine Porsche brake fluid)

**Every 4 years** (Labor operation 03 52 00 ..)

Replace tire sealant

Inspection Performed - Technician Signature: \_\_\_\_\_

**Road Test Check**

---

- Remote control, front seats, foot brake and electric parking brake (also operating travel), engine, clutch, steering, transmission, ParkAssist, automatic speed control, PSM switch, heater, air-conditioning system and instruments: Check operation

---

- Oils, fluids: Visual inspection for leaks

---

Road Test Performed - Technician Signature: \_\_\_\_\_

---

**Customer Name:** \_\_\_\_\_ **Date:** \_\_\_\_/\_\_\_\_/\_\_\_\_

**VIN: WPO** \_\_\_\_\_

**Mileage** (check one)  **Miles**  **Kilometers:** \_\_\_\_\_

**Dealer Name:** \_\_\_\_\_ **Dealer Code:** \_\_\_\_\_

**Repair Order #:** \_\_\_\_\_

**Technician Name:** \_\_\_\_\_

**Technician Signature:** \_\_\_\_\_