

Maintenance Checklist – Panamera S/Turbo (970) (2010)

Required Maintenance and Lubrication Service (USA & Canadian Vehicles Only)

* **Oil Change** Every 10,000 miles (15,000 km) or 1 year. **See Below Check Box.**

Intermediate Maintenance (Labor Operation 03 16 00 ..) See Technical Manual

After 40,000, 80,000, 120,000, 160,000 miles (60,000, 120,000, 180,000, 240,000 km) etc.

Note: If the mileage for scheduled maintenance is not reached, intermediate maintenance must be performed no later than after 4, 8, 12..... years.

The terms 'check' and 'inspection' include all necessary subsequent work such as adjusting, readjusting, correcting and topping off, but do not include repairing, replacing and reconditioning parts or assemblies.

- Diagnosis system: Read fault memory; reset maintenance interval/Read and record range information on R.O.
- Change engine oil and oil filter (Every 10,000 miles/15,000 km, see separate Oil Change Sheet, PNA 000 162 KC)
- Vehicle underside and engine compartment: Visual inspection for leaks (oils and fluids) and abrasion (lines and hoses); Underbody panels: visual inspection for completeness, secure installation and damage
- PDCC: Check fluid level
- Pollen filter: Replace filter element
- Steering gear: Visual inspection of the dust boots for damage
Tie rod ends: Check play and dust boots
- Power steering: Check fluid level
- Fuel lines and connections: Visual inspection for damage and leaks
- Radiators and air intakes: Visual inspection for external debris and blockage
Coolant: Check level and antifreeze protection level
- Brake system: Visual inspection of the brake pads and brake discs for wear
- Brake hoses and lines: Visual inspection for damage, routing and corrosion
- Drive shafts: Visual inspection of the dust boots for leaks and damage
- Axle joints: Check play; visual inspection of the dust boots for damage.
- Exhaust system: Visual inspection for leaks and damage; check mounting and heat shields
- Tires: Check condition and tire pressure
- Seat belts: Check function and condition
- Vehicle lighting: Check function
All headlights: Check setting
- Horn: Check function
- Windshield wiper/washer system, headlight washer: Check fluid level and nozzle settings (use winter antifreeze protection during winter months)
- Check wiper blades
- Clean reversing camera lense
- Battery vent hoses: Check condition
- Trailer hitch: Check operation

Additional maintenance for spark plugs (Labor operation 03 81 00 ..)

- Replace spark plugs: Panamera S every 40,000 miles (60,000 km) or every 4 years
- Replace spark plugs: Panamera Turbo every 30,000 miles (45,000 km) or every 4 years

Additional maintenance 60,000 miles (90,000 km) or every 6 years (Labor operation 03 83 00 ..)

- Replace PDCC reservoir
- PDK transmission: Change oil

Additional maintenance 80,000 miles (120,000 km) or every 4 years (Labor operation 03 85 00 ..)

- Air filter: Replace element

Additional maintenance every 120,000 miles (180,000 km) or 12 years (Labor operation 03 88 00 ..)

- Change manual transmission oil
- Change all-wheel front differential drive oil
- Change rear differential oil

Every 2 years (Labor operation 03 51 00 ..)

- Change brake fluid (use only genuine Porsche brake fluid)

Every 4 years (Labor operation 03 52 00 ..)

- Replace tire sealant

Inspection Performed - Technician Signature: _____

Road Test Check

- Remote control, front seats, foot brake and electric parking brake (also operating travel), engine, clutch, steering, transmission, ParkAssist, automatic speed control, PSM switch, heater, air-conditioning system and instruments: Check operation

- Oils, fluids: Visual inspection for leaks

Road Test Performed - Technician Signature: _____

Customer Name: _____ **Date:** ____/____/____

VIN: WPO _____

Mileage (check one) **Miles** **Kilometers:** _____

Dealer Name: _____ **Dealer Code:** _____

Repair Order #: _____

Technician Name: _____

Technician Signature: _____