

**Intermediate Maintenance Checklist – 911 Turbo (997) (2010-on)**

Required Maintenance and Lubrication Service (USA & Canadian Vehicles Only, Not For 911 GT3 (997), use separate checklist)

\* **Oil Change** Every 10,000 miles (15,000 km) or 1 year. **See Below Check Box.**

**Intermediate Maintenance** (Labor Operation 03 14 00 ..) See Technical Manual

After 20,000, 60,000, 100,000, 140,000 miles (30,000, 90,000, 150,000, 210,000 km) etc.

**Note:** If the mileage for scheduled maintenance is not reached, intermediate maintenance must be performed no later than after 2, 6, 10..... years.

The terms 'check' and 'inspection' include all necessary subsequent work such as adjusting, readjusting, correcting and topping off, but do not include repairing, replacing and reconditioning parts or assemblies.

Diagnosis system: Read fault memory; reset maintenance interval/Read and record range information on R.O.

Change engine oil and oil filter (Every 10,000 miles/15,000 km, see separate Oil Change Sheet, PNA 000 162 EF)

Vehicle underside and engine compartment: Visual inspection for leaks (oils and fluids) and abrasion (lines and hoses); Underbody panels: visual inspection for completeness, secure installation and damage

Coolant hoses: Check condition

Radiators and air intakes: Visual inspection for external debris and blockage

Coolant: Check level and antifreeze protection level

Pollen filter: Replace filter element

Brake system: Visual inspection of the brake pads and brake discs for wear (without removing wheels)

Brake hoses and lines: Visual inspection for damage, routing and corrosion

Drive shafts: Visual inspection of the dust boots for leaks and damage

Tires: Check condition and tire pressure

Check firewall and cabrio section body drains for debris

Check the door, lid locks and safety hook of the front lid for secure seating and function properly

Vehicle lighting: Check function

All headlights: Check setting

Horn: Check function

Windshield wiper/washer system, headlight washer: Check fluid level and nozzle settings (use winter antifreeze protection during winter months)

Check wiper blades

Battery: Check condition and electrolyte level

Electrical equipment, warning and indicator lights: Check function

**Additional maintenance for spark plugs** Labor operation 03 81 00 ..

Replace spark plugs every 30,000 miles (45,000 km) or every 4 years

**Additional maintenance for drive belt** Labor operation 03 60 00 ..

Check drive belt at 40,000 miles (60,000 km) or every 4 years

Check drive belt at 100,000 miles (150,000 km) or every 10 years

Check drive belt at 160,000 miles (240,000 km) or every 16 years

**Additional maintenance for convertible top** Labor operation 03 70 00 ..

Maintain and care for convertible top at 20,000 miles (30,000 km) or every 2 years

**Additional maintenance 60,000 miles (90,000 km) or every 6 years** Labor operation 03 83 00 ..

Replace drive belt

Change all-wheel drive controller oil

PDK transmission: Change clutch oil

**Additional maintenance every 120,000 miles (180,000 km) or 12 years** Labor operation 03 88 00 ..

Change manual transmission oil

Change PDK transmission oil

Change front differential oil

**Every 2 years**

Change brake fluid

**Every 4 years**

Replace tire sealant

**After 4, then every 2 years**

Check battery for the tire pressure monitoring system

**After 4, 8, 10, then every 2 years**

- Inspect airbag system
- Assembly and running gear mounts: Visual inspection of all rubber/hydraulic mounts for damage

Inspection Performed - Technician Signature: \_\_\_\_\_

**Road Test Check**

- Remote control, front seats, foot brake and parking brake (also operating travel), engine, clutch, steering, transmission, ParkAssist, automatic speed control, PSM switch, PASM switch, Sport switch, heater, air-conditioning system and instruments: Check operation
- Oils, fluids: Visual inspection for leaks

Road Test Performed - Technician Signature: \_\_\_\_\_

**Customer Name:** \_\_\_\_\_ **Date:** \_\_\_\_/\_\_\_\_/\_\_\_\_

**VIN: WPO** \_\_\_\_\_

**Mileage** (check one)  **Miles**  **Kilometers:** \_\_\_\_\_

**Dealer Name:** \_\_\_\_\_ **Dealer Code:** \_\_\_\_\_

**Repair Order #:** \_\_\_\_\_

**Technician Name:** \_\_\_\_\_

**Technician Signature:** \_\_\_\_\_